



Lamboo® Rainscreen™ w/Titan™ Clip Fastening System

Horizontal Siding Installation Guidelines using Titan™ Rain Screen Clip over Plywood or OSB

Before starting your Lamboo Rain Screen installation, check that these important items have been done properly:

Pre-Check 1 – Make sure your structural sheathing has been attached properly to the framed wall system per manufacturer’s instructions and local building codes. Plywood or Oriented Strand Board (OSB) may be used. The panel thickness should be rated for structural application and must be a minimum of 7/16” thick. Plywood is typically stiffer and stronger than OSB. Thicker plywood or OSB makes a stronger wall and has greater holding strength of the screw.

Note Foam and gypsum boards are not structural panels. (Installation of the Lamboo Rain Screen System over non-structural panels is possible – refer to Lamboo Attachment Channels and alternate installation techniques)*

Pre-Check 2 – Make sure the drainage plane material has been properly installed. Use the appropriate AWB (Air and Water Barrier) or WRB (Weather Resistant Barriers) as specified by the architect or designer. There are many products available to address requirements of the exterior wall in your climate zone.

Pre-Check 3 – All windows and exterior doors should now be installed properly. Check to ensure that the installation (and flashing) instructions from the door and window manufacturers were properly followed. *Note* Window and door manufacturer’s installation instructions always take precedent over these guidelines.*

Lamboo® Titan™ Clip Horizontal Rain Screen Siding Installation Guidelines

Titan™ Rain Screen Clip over Plywood or OSB


Step 1 – Proper acclimation is imperative. Before starting any exterior installation, *always* make sure your material has properly acclimated to local site conditions. Failure to properly acclimation on site could result in poor or undesired results. Typical acclimation time for Lamboo products is at least 48 to 72 hours prior to installation.

Step 2 – Pre-finishing all Lamboo siding boards prior to assembly is the only way to ensure that all 4 sides are coated evenly. It is highly recommended to coat all Lamboo siding with a UV inhibiting sealer prior to installation. A UV inhibiting sealer helps the Lamboo to acclimate more slowly and minimizes surface checking and movement. Lamboo typically provide materials pre-finished but if you the customer do decide to finish the materials onsite, it is important that all surfaces (edges, faces, slots, etc...) are properly coated. Be sure to follow your stain supplier’s surface prep and coating recommendations.




Step 3 – Create a level line for the starter rail on all walls. This can be done with laser lines, or a snapped chalk line. We recommend that you complete this on all walls, to ensure the starter rail level line will be consistent on all sides of the building. This step is critical to a successful siding installation and should be done with accuracy. The level line should be positioned approximately 1-1/2" above the bottom of the sheathing or 1-1/2" above the top of the foundation sill.

****Take the time to do this step well, and all your next rows of siding will be properly aligned as you build.***





Step 4 - Install Engineered Corners (Outside or Inside) you have selected (OPTIONAL). Engineered Outside Corners can be supplied if desired by the customer. Stainless steel brad nails can be used to help keep corners secured.




****NOTE:** Outside corners are typically mitered onsite. An 18-gauge brad nail can be used to help secure outside corners to keep them stable and in place. It is also recommended that Lamboo Titan Clips are positioned as close to the outside corner to help with maintaining closure and uniformity of the mitered corners.

Step 5 – Install your window and door trim. Lamboo offers window and door trim, or you can design your own. Now is the time to install them and put proper flashing in place. Always follow the window and door manufacturer's installation and flashing instructions.



B.) *If you are using 3" rain screen siding*, you will find it easier to install the Cor-A-Vent on top of the starter rail and cut it to length to fit between the rain screen clips at the top of the first course of siding. This assembly will be covered by the second course of siding as shown on the right.

Step 8 – Insert Bottom Start Piece of Lamboo Rain Screen Siding board into the Starter Rail. Place the bottom groove of the Lamboo Rainscreen material into the starter rail lip. Occasionally you may need to use a rubber mallet to seat the board properly into the clip. Seating each board properly gives the best alignment for your wall.



Important Note If your board does not seat properly, don't install it. NEVER 'force' a board into place. You may cut out any bow or bend (defect cutting) and install only the usable portion of the siding board.*

Now begin attaching the rain screen clips to the top of the siding board. Typical spacing for the rain screen clips is 16" up to 32" on center using 1 screw per clip. **Note: final on-center clip spacing will be determined at time of approved order.**

When two boards butt together, be sure to use a clip on each end of the butt-jointed boards. Using one (1) clip to support 2 boards is not recommended.

Step 9 – Repeat the clip installation process for each row of siding. A major benefit of this system is that you can use full length siding boards. Wherever you need to make a joint in the length of siding, simply use a rain screen clip at the bottom and top of the joint and straddle the two boards. You will automatically get proper alignment of the two boards. Always use two clips to secure the ends of siding boards.



When butting two siding boards together it is a best practice to use the “scarf joint” technique. A 45-degree angle at each end of cut boards work best. Master craftsmen prefer this method for best results and a quality installation you will be proud of for years. (If you use standard butt joints with 90-degree cuts, over time, the joints may open with weather exposure.)

**Note – Always apply Anchor Seal or similar end sealer product immediately after cutting any Lamboo boards. This will help minimize potential end-checking of your siding boards.*

Step 10 - Installing the top row of siding. When you reach the soffit (or areas below window openings), it is typically necessary to rip the top of the siding to the appropriate width.



Note If you trim the width ¼" narrower than required, it will be easier to install the siding and allows for better ventilation at the top of the rain screen wall cavity.*



The bottom edge of the top row of siding will seat in the rain screen clip. The top edge of the siding will need to be drilled and face screwed to blocking behind the siding. We suggest using the Coravent siding vent system or short pieces of solid wood blocking behind where you will be screwing and placing siding vent between the blocking to allow continuous uninterrupted ventilation at the top of your rain screen wall system.

For any questions about the Lamboo® Rainscreen™ System, please contact us via email at sales@lamboo.us or directly by phone at 866-966-2999. We are here to support you when using our products.